



Blackhawk Scan-To-Move

Accurate inventory is the most important stepping stone to success in repetitive manufacturing. The Blackhawk scan-to-move solution provides the tools needed to enable real-time visibility of every container in your plant. What it is. Where it is. When it got there. And who moved it.



Step One

To move a container within Blackhawk scan-to-move, the fork-lift driver first scans the container's label. This label scan informs the fork lift driver where this inventory is to be placed.

Step Two

Plant specific rules define the location or locations of where this container may be placed and enforces additional quality rules such as quarantine.



Step Three

The fork lift driver takes the container to the location specified on the tablet. Then scans the location to error proof the placement of the container and places the container at the location.